

Personalized Amplification System™

family of products

Presets 2.0 Upgrade Instructions for the PS1 Power Stand

NOTE: The upgrade procedure listed here may not be applicable for all owners. Owners must be comfortable with the use of a multimedia-equipped personal computer and a DVD player.

For software update troubleshooting, please visit the troubleshooting webpage or call the Live Music Product & Technical Support Team at (877)335-2673.

DOWNLOAD

1. Download this file and save this file somewhere locally on your hard drive where you can find it easily after the download is complete.
2. Find the update file package and extract (un-ZIP) the package. Inside the ZIP file you will find two separate .wav files and a PDF file of these same instructions.

BURN

1. Using a CD-writing application installed on your CD-writing capable personal computer, burn the two wav files each as separate audio discs. If given the options, burn as "Disc-at-Once" and turn off any normalize function.
2. Burn the file **firmware1p84.wav** to CD #1. Label the disc **CD #1 DSP Software Update 1.84**.
3. Burn the file **presets2p0.wav** to CD #2. Label the disc **CD #2 Presets 2.0 Update**.

CONNECT

1. Access the rear of the **compatible DVD player** and connect the **audio patch cable** to the DVD player's coaxial digital audio output connector. (If the player only has an optical digital audio output, a suitable adaptor must be used)
2. Connect the other end of the **audio patch cable** to the **Data In** jack (RCA-type jack with a white center) of the PS1 power stand.

NOTE: The upgrade procedure must be done in the following order with the DSP firmware update followed by the preset upgrade. The PS1 power stand may not accept the preset upgrade if the DSP firmware upgrade was not performed successfully first.

UPGRADE THE FIRMWARE

1. Turn the power switch on the PS1 power stand to **OFF**.
2. Insert the **CD #1 DSP Software Update 1.84** disc into the DVD player. Press the **STOP** button twice.
3. Turn the power switch on the PS1 power stand to **ON**. Wait for the power LED on the PS1 to go steady green.
4. Press **PLAY** on the DVD player.
5. Watch and wait. After about 8 seconds the power LED on the PS1 will blink rapidly green (about 10 times per second). The PS1 is receiving upgrade information. This normally lasts for about 10 seconds.
6. Soon after, the power LED should blink green at a slower rate (about twice per second). This would indicate that the upgrade was successful. If you are getting other results please visit the troubleshooting section.
7. Press **STOP** on the DVD player.

UPGRADE THE PRESETS

1. Turn the power switch on the PS1 power stand to **OFF**.
2. Insert the **CD #2 Presets 2.0 Update** (CD #2) into the DVD player. Press the **STOP** button twice.
3. Turn the power switch on the PS1 power stand to **ON**. Wait for the power LED on the PS1 to go steady green.
4. Press **PLAY** on the DVD player.
5. Watch and wait. After about 8 seconds the power LED on the PS1 will blink rapidly green (about 10 times per second). The PS1 is receiving upgrade information. This normally lasts for about 10 seconds.
6. Soon after, the power LED should blink green at a slower rate (about twice per second). This would indicate that the upgrade was successful. If you are getting other results please visit the troubleshooting section.
7. Press **STOP** on the DVD player.
8. Turn the power switch on the PS1 power stand to **OFF**.
9. Unplug the digital audio cable from the DVD player and PS1 power stand.
10. Turn the power switch on the PS1 power stand to **ON**. Check for a green steady power LED on the power stand. If you are getting other results please visit the troubleshooting section.

Congratulations and enjoy the new capabilities loaded into your system!